



1. Attach Pelvic and Shoulder Blocks to 3/16 Wire (Vertebral Column) with electricians tape.



2. Attach 1/16 inch twisted toe wire to all four 1/8 inch leg wires with electricians tape.



3. Bend leg wires into proper front and back leg structure

